

walbe® Charging station

Eco 2.0s

Wallbox 11 kW



INSTRUCTION MANUAL

110113-c 11/2019

TABLE OF CONTENTS

- 1 General Information.....3**
- 1.1 Introduction.....3
- 1.2 Intended Use.....3
- 2 Safety.....3**
- 2.1 Signal words.....3
- 2.2 Safety instructions.....3
- 3 Description of the charging process.....4**
- 4 Charging a vehicle.....4**
- 4.1 Meaning of the status LED colors.....4
- 4.2 Starting the charging process.....4
- 4.3 Ending the charging process.....5
- 5 Cleaning.....5**
- 6 Inspection and maintenance.....5**
- 7 Troubleshooting table.....6**
- 8 Support.....6**
- 9 Warranty.....6**
- 9.1 Warranty card.....6
- 9.2 Warranty conditions.....6
- 9.3 Warranty case.....7
- 10 Disposal.....7**
- 11 Technical Data.....8**
- 12 Directives and standards.....8**
- 13 Glossary.....8**

1 GENERAL INFORMATION

1.1 Introduction

Thank you for choosing one of our products. The charging stations of wallbe® offer convenient, safe and standard compliant charging according to the standard IEC 61851-1, charging mode 3.

Before putting the charging station into operation, read the instruction manual carefully and follow the instructions.

Also observe the vehicle-specific instructions in the instruction manual of your electric vehicle.

If you have received the instruction manual in digital form, print out the document. Keep the instruction manual stored at a safe place to have it at hand for any further reference.

Information on assembly and installation can be found in the separate installation manual.

If you sell the charging station, pass this manual on to the buyer.

1.2 Intended use


The charging station is designed for charging electric and plug-in hybrid vehicles according to charging mode 3. The charging station is mounted on a wall. Any other usage is considered to be improper and is not permitted.


The charging station wallbe® Eco 2.0s is suitable for all electric vehicles with a type 2 connection.

Persons who, due to their physical, sensory or mental abilities or their inexperience or ignorance, are unable to operate the charging station safely shall not use the charging station without the supervision or instruction of a responsible person.

2 SAFETY

2.1 Signal words

 **WARNING:** Indicates a hazard with a medium level of risk which, if not avoided, could result in serious injury or death.

 **CAUTION:** Indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.

Note: Indicates additional information, which are not hazard related.

2.2 Safety instructions

- Before each charging procedure, check whether the charging cable or the contacts of the charging plugs are damaged. Do not use a damaged charging cable. There is a risk of an electric shock!
- If you find any damage the charging cable, contact our support (see chapter 8).
- Never repair defective charging cables yourself.
- Check before each charging procedure, whether the vehicle inlet is damaged. Do not connect a charging cable to a damaged vehicle inlet.
- Ensure that the contacts of the charging plug do not come into contact with heat sources, dirt or water.
- Do not step on the charging cable or bend it.
- Make sure that neither children nor pets come near the connected charging cable. Never let children play with the charging station.
- Do not pull the plug out of the socket by the cable. Pulling on the charging cable may damage the charging cable or the locking mechanism.
- Never remove the charging cable by force. Dangerous arcs can cause serious injury or death.
- Unroll the charging cable completely to avoid overheating.
- Never open the charging station yourself. It is only permitted to qualified personnel or persons instructed by qualified personnel to open the charging station.
- Do not use the charging cable with an extension cord or adapter.
- Always make sure to remove the charging cable

from the vehicle before driving off.

- Any changes to the charging station are not permitted. There is a risk of electric shock and damage to the charging station. Any changes to the charging station will void the warranty with immediate effect.
- Never clean the charging station with harsh cleaning agents, high pressure water jet cleaners and steam jet cleaners.
- Never immerse the charging cable in water or any other liquid.
- Assembly, electrical connection, commissioning, maintenance and repair may only be carried out by a qualified electrician. The qualified electrician must be registered in the installer directory.
- If further trades are required for assembly, the necessary activities may only be carried out by trained specialists.
- No liability will be accepted for damage during transport if the product is transported in anything other than the original packaging.
- At all times, observe the local safety regulations for the country in which you operate the device.

3 DESCRIPTION OF THE CHARGING STATION

The following figure shows the wallbe® Eco 2.0s charging station. Depending on the variant ordered, the optical appearance may differ from the figure.




Figure 1: Overview of wallbe® Eco 2.0s

- A** Plastic housing
- B** Plastic holder
- C** Status LED
- D** Cable gland for power supply
- E** Firmly attached charging cable

4 CHARGING A VEHICLE

4.1 Meaning of the status LED colors

The charging station has a status LED that displays the current status of the charging station. The colours of the status LED represent the following states:

- LED shines green, the charging station is ready for use.
- LED shines blue, the vehicle is being charged. You can find out how far the charging process has progressed from the charging indicator of your vehicle.
- LED shines red, the charging station has detected an error.

4.2 Starting the charging process

⚠ WARNING: Ensure that the charging cable, when connected to the vehicle, does not block any paths of other traffic participants.

⚠ WARNING: Pay attention to the charging cable lying on the ground when the charging cable is connected to the charging station. There is a risk of tripping.

1. Make sure that the status LED shines green.
2. Connect the charging cable to the vehicle inlet of the electric vehicle.

The charging plug is automatically locked. The status

LED now shines blue.

4.3 Ending the charging process


Note: In case of power failure, the charging plug is automatically unlocked by the lock release module.

1. When the desired state of charge has been reached, you can stop the charging process, by opening the central locking of your vehicle.

Note: When the vehicle is fully charged, the vehicle will automatically stop charging.


2. Disconnect the charging cable from the electric vehicle. To do this, follow the instructions of your vehicle's instruction manual.
3. Hang the charging cable on the cable holder by loosely wrapping the charging cable around the holder.


5 CLEANING

 **CAUTION:** Finish charging before cleaning and maintenance. In addition, disconnect the charging cable from a possibly connected vehicle. Depending on the variant, stow the charging cable in your vehicle or plug the charging plug into the parking position.

You can clean the charging station as follows:

Wipe the outside of the charging station with a dry cloth.

 **WARNING:** The charging station must not be cleaned with a water or steam jet cleaner. A short circuit may be caused.

 **WARNING:** Do not use harsh cleaning agents. This can cause damage to health and the charging station.

6 INSPECTION AND MAINTENANCE

The legislator requires that the charging station and the associated sub-distribution system be checked once a year for their function and safety.

The inspection and maintenance of the charging station may only be carried out by the manufacturer or by specialist partners certified by wallbe®.

As a result of the inspection you will receive a protocol, which you should keep in a safe place.

Please also note chapter 9, Warranty.

7 TROUBLESHOOTING TABLE

Please note that as a user you may only carry out the troubleshooting measures listed in the following table yourself. All other troubleshooting measures may only be carried out by qualified personnel..

Problem	Possible cause	Solution
The charging process is not started. The status LED is still green.	The vehicle is not recognized.	First check for proper seating of the plugs on the vehicle and, if necessary, on the charging station. If the problem persists, check whether the vehicle displays an error message. If this is the case, bring your vehicle to the workshop. If the workshop determines that the vehicle is not responsible for the error message, contact our support (see chapter 8).
	Charging cable is defective	Contact our support (see chapter 8).
The status LED shines red. No vehicle is connected to the charging station.	General error	Contact our support immediately (see chapter 8).
The status LED suddenly turns red during charging.	DC error or general error	Remove the charging cable. If the status LED is still red, contact our support (see chapter 8).
Status LED does not light up.	The charging station is not supplied with power.	Contact the installer of your charging station.
	The status LED is defective.	Contact our support (see chapter 8).

8 SUPPORT

Please contact our support by e-mail. We will be happy to help you: support@wallbe.de

9 WARRANTY

9.1 Warranty card

Each wallbe® charging station is shipped with a warranty card in duplicate, one for the operator and one for the manufacturer.

Please send us the completely filled out and signed warranty card by post, e-mail or fax if the charging station was delivered in perfect condition and the installation was successful. The completely filled out warranty card is required in the case of a warranty claim.

Should the charging station show visible defects during delivery/assembly, please inform us immediately by telephone or e-mail. If you notice any physical or optical damage when the charging station arrives, please send us pictures of the damaged charging station. This will ensure a quickest possible guarantee processing.

9.2 Warranty conditions

The legal guarantee for this charging station is valid for a period of two years.

In addition, this wallbe® product is guaranteed by the manufacturer against defects in materials and workmanship for a period of four years. The warranty period begins with the purchase of the device from wallbe GmbH or from a wallbe® dealer.

The warranty for a period of four years will be granted under the following conditions:

1. The prerequisite for the warranty is the installation and annual maintenance (incl. maintenance protocol) of the wallbe® product by a certified wallbe® specialist partner.
2. It is at the discretion of wallbe® whether the warranty is fulfilled by repair or by replacement of the device or the defective part. Further claims are excluded.
3. Warranty repairs may only be carried out by wallbe GmbH. For repairs carried out by other dealers, there is no claim for reimbursement of costs within the scope of the warranty.
4. If the device is to be operated in a country other than the country for which it was originally developed and produced, changes may have to be made to the device in order to adapt it to the technical and / or safety standards of this other country.

Such changes are not due to defects in materials or workmanship and are not covered by this warranty. The costs for such changes and for damages to the device caused by the changes will not be reimbursed.

5. Excluded from the guarantee are:

- The cost of regular inspections, maintenance, repair or replacement of parts due to normal wear and tear;
- Transport and travel costs as well as costs incurred for the installation and dismantling of the device;
- Damage caused by misuse and improper use of the device, and incorrect installation;
- Damage caused by lightning, water, fire, force majeure, war, wrong mains voltage, insufficient ventilation or other reasons beyond the control of wallbe®.

6. This warranty is product-related and can be claimed within the warranty period by any person who has legally purchased the product.

7. The Buyer's statutory rights in respect of material defects to which he is entitled under the purchase contract are not restricted by this warranty.

Further information can be obtained by calling +49 (0)5252 98892-00

9.3 Warranty case

When submitting a warranty claim, you will be required to provide:

- The correctly and completely filled out warranty card,
- maintenance protocols,
- the original invoice or the sales receipt issued by the dealer, or any other corresponding confirmation,
- the device serial number.

It is at the discretion of wallbe GmbH whether the warranty obligations are fulfilled by repair or by replacement of the device or the defective part. Further claims are excluded.

For further information please contact the following number:

Tel.: +49 (0)5252 98892-00

Or visit our website:

Web: www.wallbe.de

10 DISPOSAL



Please note that this product must not be disposed of with household waste. The product must be disposed of at a designated collection and return point for the disposal and recycling of electrical and electronic equipment. Observe all applicable national and local legislation. Further information can be obtained from your local authorities.

For safety reasons, the charging station may only be dismantled by a qualified electrician or a wallbe® specialist partner. Ask your contact person whether he will take charge of the disposal for you.

11 TECHNICAL DATA

POWER CLASS 11 kW	
Construction type	Wallbox
Number of charging points	1
Charging capacity	16 A, 230 V, 3-phase
Dimensions wallbox (H x W x D)	18 x 29 x 14 cm
Weight wallbox	approx. 2,5 kg
Storage temperature	-30 to +70 °C
Operating temperature (compliant with german calibration law)	-25 to +40 °C
Operating temperature (not compliant with german calibration law)	-25 to +55 °C
Relative humidity	30 bis 95% (non-condensing)
Protection degree	IP54
Firmly attached charging cable	Type 2
Power contactor	4-pole, 25 A
Control fuse	1-pole, B6
Integrated safety devices	RCM-module – DC fault current detection. 6 mA contactor monitoring Lock release module
RCD (must be installed in the sub-distribution)	Type A 0,03 A / 25 A
Circuit breaker	Not integrated
Authorization	No
Housing lockable	No
Energy meter	No
Protocols	Modbus TCP/RTU
Interfaces	Ethernet RJ45, RS485
Protection class	1

12 DIRECTIVES AND STANDARDS

The following guidelines and standards have been observed:

Directives

- Low Voltage Directive 2014/35/EU
- EMC-Directive 2014/30/EU
- RoHS Directive 2011/65/EU
- WEEE-Directive 2012/19/EU

Standards

- EN 61851-1
- EN 61439-7
- EN 61000-6-2
- EN 61000-6-3
- EN 61000-3-2
- EN 61000-3-3

13 GLOSSARY

Unfortunately, technical terms cannot always be avoided. In our glossary you will therefore find some technical terms and abbreviations briefly explained:

Vehicle inlet

The charging plug of the charging cable is inserted in the vehicle inlet of the electric car. The vehicle inlet is, so to speak, the socket of the electric vehicle.

Charging mode 3

Charging mode 3 is used for single-phase or three-phase alternating current charging with permanently installed charging stations. Alternating current charging is controlled by communication between the charging station and the vehicle. Among other things, the charging station is able to detect the charging power of the charging cable, the interruption of the charging process and the maximum available charging current.

Circuit breaker

Circuit breakers disconnect the circuit from the mains if the current exceeds a certain value due to overload or short-circuit.

Lock release function

The lock release function ensures that the charging plug is automatically unlocked when the power fails during charging.

RCD (Residual-Current Circuit Device)

A residual current device (RCD), also known as residual current circuit breaker, is a fault current protective device that interrupts a circuit when a so-called residual current is detected. This can occur if a small part of the current passes through the human body and does not flow back into the circuit via the RCD. RCDs trip at 30 mA at the latest.

Contactors monitoring

By the contactor monitoring, it is determined whether the contacts of the contactor are welded (glued) due to a defect. In the event of such a fault, a dangerous voltage is still present and the status LED lights red.

Sub-distribution

The sub-distribution serves to distribute the electricity in the house. It is located in the so-called fuse box and consists of various switching and fuse elements.



CE

110113 is the original instruction manual.

©2019 wallbe®. All rights reserved.

This document may not be copied in whole or in part or reproduced in any form or form without the written permission of wallbe GmbH. All illustrations in this manual are only examples and may differ from the delivered product. All information in this manual may be changed without prior notice and does not represent any obligation on the part of the manufacturer..

wallbe®

Paderborner Straße 76
33189 Schlangen
Tel.: +49 (0) 5252 98892-00
beratung@wallbe.de
www.wallbe.de